EVEREST BACKPACK

USER MANUAL

FURCHTLOS

INCLUDED

EVEREST Backpack

Removable Laptop Organizer

CLOSING THE BACKPACK

1. Roll the mouth of the bag at least three times for a watertight seal. Then fasten the buckles on either side of the bag and pull the webbing ends to tighten the straps.

2. After tightening, the excess webbing length can be folded and secured with the hook and loop strip at the end of the webbing.

3. If needed, use the air valve on the side of the bag to release any extra air inside.

USING THE STORAGE PANEL

The front hypalon cover can be expanded to hold a helmet, drybag, jacket or other items.

1. Release the plastic buckle in the front of the backpack and adjust the strap to the desired length.

2 Unhook the G hooks from the sides of the backpack and adjust the straps to the desired length.

3 Place your items between the backpack and the hypalon cover. If needed, release the hook and loop strip in the base of the hypalon cover to expand it further. Then refasten the central buckle and the 4 G-hook straps on the sides of the backpack and pull the loose webbing ends to tighten all five straps.

4 After tightening, it's recommended to fold and secure the excess webbing length with the hook and loop strips or elastic band at the end of the webbing.

WEARING THE BACKPACK

⚠ Note: When wearing the backpack it's recommended to use the waist and chest straps to better distribute the weight of the load. Adjust the straps to a comfortable position, then tighten them as much as possible to reduce the pressure on the shoulders.

WARNINGS & GUIDELINES

WARNING!

Please read the user manual carefully and follow the recommended assembly method.

It's recommended to check that the bag is securely attached before each operation of the motorcycle.

Do not drive the motorcycle with a bag that is not fully closed, is not properly secured, or in any other condition that may affect the safe operation of the vehicle.

Ensure that no part of the bag, including the fixation straps or other accessories, has close contact with high temperature areas such as the exhaust pipe.

CLEANING & MAINTENANCE

To maintain a nice appearance, it's recommended to use silicone lubricant spray and a soft cloth to wipe the bags clean.

Do not use harsh cleaning agents, chemicals or high pressure cleaners.

When the surface material is exposed to direct sunlight for a long time or is affected by environmental factors (such as haze, acid rain, etc.), the color may fade or change.

If the product is contaminated with gasoline or similar substances it must be cleaned immediately!

FURCHTLOS does not assume any responsibility for product damage and color change caused by improper cleaning and maintenance!

CLEAN WITH A DAMP CLOTH OR SOFT SPONGE

DO NOT PRESSURE WASH

CLEAN GASOLINE OR OTHER SPILLS IMMEDIATELY!

DO NOT USE CHEMICALS OR HARSH CLEANING AGENTS

VIDEO TUTORIAL

WARRANTY REGISTRATION

FOLLOW & TAG US
@FURCHTLOSMOTO_

www.furchtlos-moto.com